



Travel Unburdened, Live Unrestrained

Travel Laptop Backpacks

Laptop-Rucksäcke

USER MANUAL

MODEL NO.
25LB-U06


Capacity
40L

Weight
1.95kg/4.30 lbs


Width
12.20in/31cm

Height
21.65in/55cm

Depth
9.84in/25cm




KEY FEATURES




MADE FROM RECYCLED POLYESTER


PRODUCT OVERVIEW



PRODUCT OVERVIEW



ERGONOMIC & SAFETY FEATURES



3D Breathable Back Panel Improves airflow and carrying comfort.

Reflective Webbing Enhances visibility in low-light environments.


Hanging Strap Convenient for hanging on hooks or supports.

Chest Straps with Whistle Buckle Shock absorption, weight reduction, and emergency safety.


Luggage Strap Secures the backpack onto suitcase handles for easy travel.

INTERIOR LAYOUT OF MAIN COMPARTMENT

Padded Laptop Storage (Fits up to 15.6")



When the main pocket is full and you need to take out the computer, just open the quick-access zipper on top to get it in or out.



TOILETRY BAG

Capacity: 5L / For Cosmetics/Toiletries



Smaller Packing Bag

Capacity: 6L / Fits 1 shirt + 3 tees + 2 pants



Larger Packing Bag


Capacity: 7.5L / Fits 1 shirt + 4 tees + 3 pants



MULTIPLE CARRYING OPTIONS


1. Backpack Mode

- A. Release buckles
- B. Attach to shoulder strap attachment point
- C. Secure buckle lock




2. Hand-Carry / Luggage Mode


- A. Release buckles
- B. Stow shoulder straps
- C. Secure the buckle
- D. Hand carry with the side handles or attach to luggage



3. Shoulder Bag Mode for the Packing Bags



- A. Take out shoulder strap from the toiletry pocket
- B. Release the buckles
- C. Attach the shoulder strap to the orange loops of the packing bags
- D. Adjust the length according to needs



CLEANING AND MAINTENANCE

1. Cleaning Instructions

- Hand wash only with a damp cloth and mild detergent
- Air dry naturally—do not machine wash
- Avoid bleach to protect fabric coating
- Note: Machine washing may damage zippers and hardware

2. Storage Instructions

- Store in a dry, well-ventilated area away from direct sunlight
- Avoid heavy pressure or prolonged folding
- For long-term storage, fill with soft items (e.g., clothes) to maintain shape

3. Care Instructions

- Do Not Iron
- Do Not Bleach
- Hand Wash Only
- Do Not Dry Clean
- Line Dry in the Shade
- Do Not Machine Wash

EC REP

Company Name: REPLAB SARL
Address: 99 AVENUE ACHILLE PERETTI
92200 NEUILLY-SUR-SEINE France
Email: EUREP@REPLAB.CC
Phone: +33767189223
Contact: XIAOLAN LIU

UK REP

Company Name: REPLAB CON SULTING LTD.
Address: 376 NEWPORT ROAD CARDIFF, WALES,
CF23 9AE
Email: UKREP@REPLAB.CC
Phone: +447395577022
Contact: HUIHUA LU



Made in China/Hergestellt in China/
Fabrique en Chine/Fatto in Cina/Hecho en China

JOIN US FOR EXCLUSIVE BENEFITS!



WARRANTY
1+1
YEARS

Enjoy These Exclusive Perks

- ✓ After-sales issues prioritized.
- ✓ Special promotions for registered users.
- ✓ Be the first to know about new products.
- ✓ 1 Year Warranty + 1 Year Extra with Registration!

Need Help?

For questions or assistance, feel free to contact us:
service@tolacca.com / @tolacca

